

# Instytut Inżynierii Chemicznej

Adres artykułu: <https://iich.gliwice.pl/pl/artykul/data-concerning-adsorption-equilibria-of-carbon-dioxide-nitrogen-and-oxygen-over-a-zeolite-molecular-sieve-13x-for-the-modelling-of-carbon-dioxide-capture-from-gaseous-mixtures-by-adsorptive-processes>

## Data concerning adsorption equilibria of carbon dioxide, nitrogen and oxygen over a zeolite molecular sieve 13X for the modelling of carbon dioxide capture from gaseous mixtures by adsorptive processes

<b>Data publikacji:</b>	01.06.2020
<b>Tytuł publikacji:</b>	<a href="https://iich.gliwice.pl/pl/artykul/data-concerning-adsorption-equilibria-of-carbon-dioxide-nitrogen-and-oxygen-over-a-zeolite-molecular-sieve-13x-for-the-modelling-of-carbon-dioxide-capture-from-gaseous-mixtures-by-adsorptive-processes">Data concerning adsorption equilibria of carbon dioxide, nitrogen and oxygen over a zeolite molecular sieve 13X for the modelling of carbon dioxide capture from gaseous mixtures by adsorptive processes</a>
<b>Autorzy:</b>	<a href="#">Marek Tańczyk</a> , <a href="#">Manfred Jaschik</a> , <a href="#">Aleksandra Janusz-Cygan</a> , <a href="#">Jolanta Jaschik</a>
<b>Informacje o czasopiśmie:</b>	<a href="#">Data in Brief</a>

Experimental adsorption isotherms of carbon dioxide, nitrogen and oxygen at 293, 313 and 333 K over a zeolite molecular sieve 13X Grace are presented. The data were used in the simulations of the hybrid VSA-membrane process for carbon dioxide capture from flue gas as presented in a related article entitled “The performance of a hybrid VSA-membrane process for the capture of CO<sub>2</sub> from flue gas”[1]. A representative sample of ZSM 13X Grace (149.7 mg) was prepared using the Microscal Spinning Riffler. Adsorption equilibria were determined by a gravimetric method, which uses a microbalance IGA003, Hiden Isochema Ltd., UK at temperatures of 293, 313 and 333 K. Every adsorption isotherm was started at 0 bar. For CO<sub>2</sub> the equilibrium concentration reaches 3.755- 4.857 mol kg<sup>-1</sup> at the maximum pressure of 1 bar. In the case of N<sub>2</sub> and O<sub>2</sub> the equilibrium concentration reaches, respectively, 0.721-1.255 mol kg<sup>-1</sup> and 0.299-0.531 mol kg<sup>-1</sup> at the maximum pressure of 5 bar. Data may be reused in any adsorptive CO<sub>2</sub>/N<sub>2</sub>/O<sub>2</sub> separation process which uses ZMS 13X as an adsorbent.

# Metryczka

<b>Opublikował w BIP:</b>	Marek Tańczyk
<b>Data opublikowania:</b>	11.05.2026 09:39
<b>Liczba wyświetleń:</b>	5